

User Manual

Installation

Mount the screws on the wall at a recommended height of 5 ft. The distance between the screws should be 20 cm. Once the screws are mounted on the wall. Lift the unit and hang it on the screws.

Take care not to damage the nozzle which is at the bottom end of the product. The nozzle should thus be at an approximate height of 120 cm from the ground for best use.



Starting the product.

Open the lid and fill up to 5 liters of sanitizer into the tank. Close lid firmly





Ensure that the lid is closed and plug-in the attached wire into an electrical socket. Switch it ON. Wait for ten seconds after the red light has turned on. Now your device is ready for use.

How to use

Extend your hand and show two open palms under the device where this sticker is positioned. In about two seconds, the indicator green light will come on and dispensing will begin. Once dispensing begins rub your hands together and cover entire surface of your palms till the dispensing light switches off.





Refilling

A fully filled tank should last up to 1000 cycle of sanitization. The level of sanitizer is visible from front panel.



Once sanitizer level reaches the "refill now" sticker please refill the tank as mentioned above.

